



WATER HEATER

All our RV's are equipped with a 6 gallon propane-fired water heater. They use propane to fire the burner and a 12v igniter to light it. The igniter is electronic and you don't have to manually light the water heater. (However, there are a couple of travel trailers in stock that have specifically manual lighting water heaters, you should be informed of this at the time of pickup) These units are the "quick recovery" type and can generally reheat the tank in 20 to 30 minutes, making it possible for several people to shower without waiting extended periods of time in between.

Follow these steps to light the water heater.

- 1.) Make sure you have propane and the valve on the propane tank is open. (If you're not sure, light a burner on the stove. **This will also purge any air that might be trapped in the lines.**)
- 2.) Make sure you have water in the water heater. (Check this by turning on the hot water side of the faucet in either the kitchen or bathroom.)
- 3.) Locate the water heater ON/OFF switch. (Usually found on the monitor panel or in the kitchen area. This switch usually has a red light lens on it.)
- 4.) Press the switch to the ON position. The red light should come on for a couple of seconds and go off. You should hear the burner fire on the water heater.

You should begin to feel warm water from the hot water tap within 5 to 10 minutes. If you don't or aren't sure the water heater lit. Turn the switch off, wait a few seconds and turn it back on.

If the red light stays on continuously, the water heater isn't lit. If, after trying the above procedures several times, the water heater doesn't light, call our customer service line for assistance.